

KITLEDBKLT16EVBE Evaluation Board




Table of Contents

1 Kit Contents / Packing List	2
2 Important Notice	3
3 Kit Introduction	4
4 Required Equipment	4
5 EVB Setup Configuration Diagram	5
6 EVB Schematic	6
7 Using Hardware	7
8 Board Layout	8
9 Bill of Material	13
10 References	14
11 Revision History	15



1 Kit Contents / Packing List

- LED Load Board

2 Important Notice

Freescal provides the enclosed product(s) under the following conditions:

This evaluation kit is intended for use of ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY. It is provided as a sample IC pre-soldered to a printed circuit board to make it easier to access inputs, outputs, and supply terminals. This EVB may be used with any development system or other source of I/O signals by simply connecting it to the host MCU or computer board via off-the-shelf cables. This EVB is not a Reference Design and is not intended to represent a final design recommendation for any particular application. Final device in an application will be heavily dependent on proper printed circuit board layout and heat sinking design as well as attention to supply filtering, transient suppression, and I/O signal quality.

The goods provided may not be complete in terms of required design, marketing, and or manufacturing related protective considerations, including product safety measures typically found in the end product incorporating the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. In order to minimize risks associated with the customers applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards. For any safety concerns, contact Freescale sales and technical support services.

Should this evaluation kit not meet the specifications indicated in the kit, it may be returned within 30 days from the date of delivery and will be replaced by a new kit.

Freescal reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts.

Freescal does not convey any license under its patent rights nor the rights of others. Freescale products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale product could create a situation where personal injury or death may occur.

Should Buyer purchase or use Freescale products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale was negligent regarding the design or manufacture of the part. Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2008

3 Kit Introduction

This LED Load Board is designed for use with all Freescale LED driver demo boards that support up to 16 channels. The board contains 256 LEDs arranged in 16 channels of 16 LEDs each. The board is connected to the driver PCB with a cable that connects only the number of channels supported by the driver demo board. For each channel, jumpers enable the number of LEDs per channel which can be configured. These jumpers also enable fault detection and allow performance to be evaluated. Push-pin connectors enable the board to be connected to any driver system.

This KIT is an LED Load Board intended for use with any LED driver.

3.1 KITLED BKLT16EVBE Features

- 16S16P LED Matrix
- Current capability up to 180mA on each channel.
- Typical LED forward voltage equal to 3.5V @ 25°C
- LED shorting jumpers for series and parallel configurations
- Versatile LED channels connections
- 2 Layers Board
- Special connector and cable for KIT34844EPEVME interface (J115)
- Terminal Block for any LED Channels configuration (J114).

4 Required Equipment

- Freescale LED driver evaluation board
- LED Load Board - KITLED BKLT16EVBE

5 EVB Setup Configuration Diagram

This configuration Diagram shows an LED Load Board configuration with “KIT34844EPEVME”




Figure 1. EVB Setup Configuration Diagram

6 EVB Schematic




Figure 2. KITLEDBKLT16EVBE Schematic

7 Using Hardware

7.1 Jumper Connections




Figure 3. KITLEDCLK16EVBE Jumpers

LOCATION	REFERENCE DESIGNATOR	DESCRIPTION
Top Horizontal	J1 to J16	LED channel string enable
Bottom Horizontal	J97 to J112	It connects the Bottom of the LED channel to V+
Vertical	J17 to J96	Short Circuit LED

8 Board Layout

8.1 Assembly Layer Top (x0.75)




Figure 4. Assembly Layer Top

8.2 Assembly Layer Bottom (x0.75)




Figure 5. Assembly Layer Bottom

8.3 Top Layer Routing (x0.75)




Figure 6. Top Layer Routing

8.4 Bottom Layer Routing (x0.75)




Figure 7. Bottom Layer Routing

8.5 Fabrication Drawing




Figure 8. Fabrication Drawing

9 Bill of Material

Schematic Designator	Device	Type	Description	Manufacturer PN
Capacitors				
C24	0.1UF	CC1206_OV	CAP CER 0.1UF 100V 5% X7R 1206	C1206C104J1RACTU
Diodes - LED				
D1 - D256	NFSW036BT	LED_3p5X3p5	LED WHITE SGL 180mA 3.5V SMT	NFSW036BT
Header				
J1 - J112	HDR_1X2_M	HDR102_A	HDR 1X2 TH 100MIL SP 408H AU	5-146276-2
Terminal Block				
J113	CON_2_TB	con2x2_tb_3p5_th	CON 1X2 TB TH 3.5MM SP 508H SN	1885180000
J114	CON_16_TB	con16_tb_3p5_th	CON 1X16 TB TH 3.5MM SP 508H SN	1885320000
Connector				
J115	CON_1X12	hdr_12_xask	CON 1X12 PLUG SHRD TH 2.5MM SP 346MIL SN	B12B-XASK-1N-A
Bannana Jack				
J117 - J118	BANANA	banana_jack_6p9	CON 1 BANANA UNINSULATED TH -- 531H NI	108-0740-001
Resistors				
R1	2.2	RC0805_OV	RES MF 2.20 OHM 1/8W 1% 0805	CRL0805-FW-2R20EL F

10 References

Following are URLs where you can obtain information on other Freescale products and application solutions:

Description	URL
Freescale's Web Site	www.freescale.com
Freescale's Analog Web Site	www.freescale.com/analog
Freescale's Power Management Web Site	www.freescale.com/powermanagement
Freescale's LED Drivers	www.freescale.com/webapp/sps/site/taxonomy.jsp?code=LEDBLDRIVER

11 Revision History

REVISION	DATE	DESCRIPTION OF CHANGES
1.0	10/2008	Initial Release

How to Reach Us:

Home Page:

www.freescale.com

Web Support:

<http://www.freescale.com/support>

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
+1-800-521-6274 or +1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd.
Exchange Building 23F
No. 118 Jianguo Road
Chaoyang District
Beijing 100022
China
+86 10 5879 8000
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc., 2008. All rights reserved.